

VE3TBR System Codes

August 1987

Voice ID - System access

911 - Emergency (Direct access)

Dial In...767-7661

<\*><Release PTT> - To answer phone or access autopatch direct dial.

<#> - Terminate all functions (END)

| FUNCTIONS           | EMERGENCY SPEED DIAL             | PERSONAL SPEED DIAL |
|---------------------|----------------------------------|---------------------|
| *1 - Autopatch (AP) | *100 - (OPP) T. Bay Detachment   | *1nn (Home No.)     |
| *2 - Test pad (R)   | *200 - (KB OPP) Kekabeka Detach. | *2nn .....          |
| *3 - n/a            | *300 - (MKG) McKellar General    | *3nn .....          |
| *4 - n/a            | *400 - (PAG) Pt. Arthur General  | *4nn .....          |
| *5 - n/a            | *500 - (SJG) St. Joseph's Hosp.  | *5nn .....          |
| *6 - n/a            | *600 - (EMO) Emergency Measures  | *6nn .....          |
| *7 - n/a            | *700 - (RED X) Red Cross         | *7nn .....          |
| - Time (EDT)        |                                  | *8nn .....          |
| 9 - Redial (RD)     | 911 - (EME) Police, Fire, Ambul. | *9nn .....          |
|                     |                                  | *0nn .....          |

L.A.R.C. Members Personal Codes (nn)

|        |        |        |        |        |        |        |
|--------|--------|--------|--------|--------|--------|--------|
| AHD 32 | CK 56  | GOM 68 | JAA 21 | LMG 12 | OPW 82 | PHU 67 |
| AJ 62  | CX 69  | HFS 16 | JAB 37 | LMI 17 | OPZ 42 | SNW 22 |
| ARN 11 | DJM 51 | HMU 80 | JAJ 55 | LML 36 | OTC 73 | XJ 15  |
| AUP 72 | DPJ 86 | HTM 44 | JAU 49 | LMN 27 | OTI 39 | XT 18  |
| AVS 76 | ECV 24 | HXK 38 | JQ 25  | LMV 48 | OTW 83 | ZG 19  |
| AYZ 13 | EDX 85 | HZW 57 | JSC 75 | MOE 71 | OTZ 78 | ZRX 74 |
| BBS 23 | EDZ 61 | ICY 35 | KRH 45 | NHX 14 | PHK 84 |        |
| BCD 28 | EFC 50 | ILV 90 | KRN 65 | NNO 31 | PHL 59 |        |
| BCX 91 | EFZ 33 | ILX 81 | KRP 88 | OPI 47 | PHN 58 |        |
| BQR 79 | EJJ 53 | IY 64  | KRV 70 | OPL 30 | PHT 54 |        |

August Update

- On some occasions when dialing a number using the autopatch direct dial mode, the local phone system will not accept all the tones generated by your radio. If this happens, you have the option of using the redial feature as previously described or you can use the autopatch computer dial function. This can be done by accessing the repeater as usual and then pressing <\*><1>. Now listen for "AP" in CW. Next enter the number you wish the computer to dial for you and listen for the call to be completed. Proceed as you would with any other autopatch call.